



Topaz – Wi-Fi Communication

Table of Contents:

1. Introduction2

2. Step by Step Configuration2

 a. Topaz Configuration2

 b. GenMix Pro Configuration5

3. Test the connection7

 a. From GenMix Pro7

 b. From windows command line (DOS)7

4. Contact information8



1. Introduction

The Topaz can be connected to the GenMix Pro through Wi-Fi.


2. Step by Step Configuration

***P.S: The IP distribution on the network should always be set to DHCP “Automatic”
We recommend to setup the device in the presence of an IT specialist***

- a. Topaz Configuration
 - i. Turn on the device
 - ii. Access the main page from the settings



- iii. Click on the down arrow to scroll to next page





- iv. Select Wi-Fi ON



- v. Turn the Wi-Fi ON
- vi. Click again on Wi-Fi ON and select Wi-Fi Setup






- vii. Wait until the Topaz scans for available networks and connect the Topaz to the same network your PC is connected to.




- viii. Enter your Network's password, then click on the "✓" symbol




- ix. The device is now connected to the network.



- x. Go back to the Main Page and click on Connect.



- xi. If the Topaz is connected normally, a green checkmark will appear next to "Wi-Fi Network". Application SW means that the device is connected to the software.



b. GenMix Pro Configuration

- i. Connect the Topaz to your PC via USB



- ii. Open GenMix Pro Software
iii. Access the Parameters
iv. In General section, find the dropdown with the spectrophotometer models



- v. Select “Topaz” from the dropdown.

- vi. Click the Save icon




- vii. After saving the “Additional Settings” button appears. Click on it to access it

- viii. *Topaz Additional Settings* window opens.
Enter the topaz IP Address or click on “Fill Hostname”, to add the topaz hostname automatically (for more information about the hostname, please check with your IT specialist)



- ix. Tick the Enable Topaz Wi-Fi checkbox




- x. Click on Save.


3. Test the connection

- a. From GenMix Pro

- i. In the *Topaz Additional Settings* window, click on “Test Connection” button.



- ii. If the Topaz is connected normally, you will receive the following message:




- iii. You can use now the Topaz in GenMix Pro through Wi-Fi.

- b. From windows command line (DOS)

Warning: this section is considered advanced and requires the presence of an IT specialist

- i. Open “Command Prompt” application from Start Menu.



- ii. Type the command below: “ping (Add the Topaz’s IP address) -t”

```
ping 192.168.0.32 -t
```

- iii. Click Enter.



- iv. If the Topaz is connected normally, the below will be displayed:

```
Reply from 192.168.0.32: bytes=32 time=51ms TTL=128
Reply from 192.168.0.32: bytes=32 time=6ms TTL=128
Reply from 192.168.0.32: bytes=32 time=27ms TTL=128
Reply from 192.168.0.32: bytes=32 time=5ms TTL=128
Reply from 192.168.0.32: bytes=32 time=14ms TTL=128
Reply from 192.168.0.32: bytes=32 time=6ms TTL=128
```

After testing the connection, you can unplug the USB cable and connect to the Topaz as if it was still connected via USB.

4. Contact information

For more information or comments, please do not hesitate to contact the General Paint Software support team by email at support.it@generalpaint.biz

Or by phone at +961 9 925 990

We are available from 8:00AM (GMT) to 6:00PM (GMT).